

Parts list for page 10 illustration

KEY NO.	PART NO.	DESCRIPTION
1	7224087	Screw, #8-32 x 1" (2 req.)
2	7286039	Motor (incl. 2 ea. of Key No. 1)
3	7231393	Motor Plate
4	0900857	Screw, #6-20 x 3/8 (3 req.)
5	7171250	Bearing
6	7283489	Cam & Gear
7	7169180	Clip (Drain)
8	7172793	Drain Hose Adaptor ▲
8a	7271270	Drain Hose Adaptor
9	7170288	O-ring, 15/16 x 1-3/16
10	7211644	Flow Plug, 2.0 gpm ▲
10a	0501228	Flow Plug, 2.0 gpm
11	7170327	O-ring, 5/8 x 13/16
12	7173024	O-ring, 1-1/8 x 1-1/2
13	7174313	Bearing, Wave Washer
14	7185500	Rotor & Disc
15	7173032	O-ring, 4-1/2 x 4-7/8
16	7185495	Rotor Seal
17	7172989	Seal
18	7171187	Plug (Drain Seal)
19	7129889	Spring
20	7089306	Clip (2 req.)
21	7077642	Copper Tube, 1" (2 req.)
22	7170262	O-ring, 1-1/8 x 1-3/8 (4 req.)
23	7094898	Turbine Support
24	7101548	Turbine
25	7276084	Wire Harness (Sensor)
26	0900060	O-ring

KEY NO.	PART NO.	DESCRIPTION
27	7081201	Retainer (Nozzle & Venturi)
28	7195482	Seal (Nozzle & Venturi)
29	7171145	Valve Body
30	7170319	O-ring, 1/4 x 3/8 (2 req.)
31	7081104	Nozzle & Venturi Housing
32	1202600	Nut - Ferrule
33	7095030	Cone Screen
34	1148800	Flow Plug, .3 gpm
35	7114533	Nozzle and Venturi - Gasket Kit
	7204362	Gasket (only)
36	7084607	Flow Plug, .15 gpm
37	7146043	Screen
38	7167659	Screen Support
39	7170262	O-ring, 1-1/8 x 1-3/8
40	7199729	Cap
41	7175199	Wave Washer
42	7171161	Valve Cover
43	7172997	Screw, #10 x 2-5/8 (8 req.)
44	7305150	Switch
45	7140738	Screw, #4-24 x 3/4 (2 req.)
46	7248706	Ground Kit
47	7214383	Bypass Valve (optional)
◆	7253808	Nozzle & Venturi Asm (incl. Key Nos. 31, & 33 – 40)
◆	7185487	Seal Kit (incl. Key Nos. 11, 12, 15, 16, 17 & 28)

◆ not illustrated

▲ for units built before June 15, 2005